

PRODUCT LIST

1936 FORD TOURER

FRONT FLOOR SECTION

This panel begins at the bottom of the firewall and continues through to the front of the rear seat riser.



REAR FLOOR SECTION

This panel starts at the front of the rear seat riser and continues to the back panel or tool box area.



SILLS (SET OF 4) (rocker panels)

The sills/rockers panels come in 4 sections. The front section's, L&R, start at the lower cowl area and continue under the "A" pillar and finish at the "B" pillar. The rear section's, L&R, start at the "B" pillar and continue through to the start of the rear inner wheel arch or the "C" pillar /dog-leg panel.



FIREWALL 5" RECESS

The recessed firewall is a full replacement unit, the old unit needs to be "unpicked" and the new unit will need to be spot-welded into place....the 5" unit is suited to big block conversions



FIREWALL 3" RECESS

The 3" unit will suit most small block conversions.

TRANSMISSION TUNNEL

(Hotrod)

The transmission tunnel is for "hot-rod" use only, and will cater for most conversions.



Note: pictures not to scale

CALL OR EMAIL WADDINGTONS FOR CURRENT PRICING